

THE LEADING EDGE IN KNIVES & MORE
EST. 2017



OLDE TOWNE

— *Cutlery* —



**SHEATH
FORMING**



**How to “Wet-Form”
Leather Sheaths**



1. Choose proper un-oiled sheath.
2. Knife should fit **VERY** snug.
3. Wrap knife in Saran Wrap to avoid staining or corrosion.
4. Fill sink with warm water and immerse sheath until saturated.
5. Insert knife into sheath.
6. **FIRMLY** massage the leather around the contours of the knife handle; forming a shaped pocket.
7. Remove knife and set sheath in a warm dry place and air dry.
8. **DO NOT HEAT IN OVEN!**
9. A properly wet-formed sheath will contract slightly for a perfect fit.
10. Only periodic oiling of the sheath is necessary for years of service.

KNIFE SHOP

4320 Settendown Village Rd Suite 700
Cumming, GA 30041
Info@OTCutlery.com
1-833-GOT-KNIVES